iSpeed for CGO600 pro *installation manual (CGO600 pro only)*

STEALTH INSTALL (UNDERNEATH THE BIKE BATTERY)

WARNING: Make sure your e-bike is turned off !

- 1. Remove the bike battery with your key
- 2. Remove the cable cover (small hole on the top)
- 3. There are two connectors, disconnect the GREEN connector (the RED connector is for the light) *
- 4. Connect the iSpeed blackbox to the two green connectors
- 5. Place the iSpeed black box with the sticker facing down, move the foam cable to the left and other cables to the right to create room
- 6. Push the cable cover back in place and install the battery



Version 1.2 Nov 2, 2023

* For some bikes the connectors are hidden underneath the battery connect plate, loosen it to access the connectors. TIP: keep the battery lock key installed so it is easier to re-install the lock.