iSpeed for CGO600 *installation manual (CGO600 only)*

STEALTH INSTALL (UNDERNEATH THE CRANKSHAFT)

WARNING: Make sure your e-bike is turned off !

- 1. Place your e-bike upside down on a soft surface and remove the black cable cover (2x Philips screw)
- 2. Locate the GREEN display connector and connect the iSpeed blackbox
- A DO NOT disconnect the ribbed Torque sensor or Motor connector! (risk of damage)
- 3. Install the iSpeed blackbox and route the cables (tight fit!)
- 4. Re-install the cable cover with the 2x Philips screws and enjoy!

