

iSpeed for CG0800 / Comate CC/CT *installation manual*

STEALTH INSTALL (UNDERNEATH THE BIKE BATTERY)



WARNING: Make sure your e-bike is turned off !

1. Remove the bike battery with your key
2. Remove the cable cover (Use an allen key in small hole on the top)
3. There are two connectors, disconnect the Black or GREEN connector as also used on your iSpeed box
4. Connect the iSpeed blackbox to these two connectors
5. Place the iSpeed black box with the sticker facing down, move the foam cable to the left and other cables to the right to create room
6. Push the cable cover back in place and install the battery

