## **iSpeed for CGO800S and Comate CC/CT** *installation manual*





## WARNING: Make sure your e-bike is turned off !

- 1. Unplug the display cable of your Tenways CGO800S / Comate CC/CT
- 2. Connect the iSpeed blackbox to the two black connectors
- 3. Secure the blackbox with a zip tie and enjoy

