

# iSpeed for CG0600 & CG0800 Plus

## *installation manual*

### STEALTH INSTALL (INSIDE THE BIKE FRAME)

---



**WARNING: Make sure your e-bike is turned off !**

1. Remove the cable cover (small hole on the top / bottom)
2. Remove the bike battery with your key and remove the lock plate (5 Philips screws, pay attention to the location of the different screws)
3. Identify the CAN display cable with the green 5 pin connector



4. Connect the iSpeed box to the CAN display cable and push the iSpeed box down into the frame underneath the controller. Mount the lock plate again (insert the key to hold it) and push the cable cover back in place.
5. Enjoy!

